

**HP 3000 Computer Systems**

# **SERIES 64/68 4 MEGABYTE MEMORY ADD-ON**

**Installation Manual**



19447 PRUNERIDGE AVENUE, CUPERTINO CALIFORNIA 95014

#### **NOTICE**

The information contained in this document is subject to change without notice.

HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

Hewlett-Packard assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Hewlett-Packard.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another language without the prior written consent of Hewlett-Packard Company.

Copyright © 1985 by HEWLETT-PACKARD COMPANY

## LIST OF EFFECTIVE PAGES

The List of Effective Pages gives the date of the most recent version of each page in the manual. To verify that your manual contains the most current information, check the dates printed at the bottom of each page with those listed below. The date on the bottom of each page reflects the edition or subsequent update in which that page was printed.

Effective Pages

Date

All . . . . . Jul 1985

## PRINTING HISTORY

New editions are complete revisions of the manual. Update packages, which are issued between editions, contain additional and replacement pages to be merged into the manual by the customer. The dates on the title page change only when a new edition or a new update is published. No information is incorporated into a reprinting unless it appears as a prior update; the edition does not change when an update is incorporated.

The software code printed alongside the date indicates the version level of the software product at the time the manual or update was issued. Many product updates and fixes do not require manual changes and, conversely, manual corrections may be done without accompanying product changes. Therefore, do not expect a one to one correspondence between product updates and manual updates.

First Edition . . . . . Jul 1985

This manual describes how to add Main Memory Array (MMA) PCAs (P/N 30140-60170) to an HP Series 64/68 Computer. The procedure is as follows:

1. Perform a system back-up.
2. Perform an MPE shutdown.
3. Turn off main power to the computer.

**CAUTION**

During the next step be sure to wear a grounding strap and follow standard ESD precautions when handling PCAs.

4. See Figure 1. The MMA PCAs are assigned to the last eight slots at the right end of the CPU Bay card cage. Do not skip any slots! Push the new MMA PCAs far enough into their respective card cage slots until you can feel them enter and seat into the backplane connectors.

**CAUTION**

If 4 Mbyte memory arrays (p/n 30140-60170) are to be added to a system that has 1 Mbyte arrays (p/n 30140-60014), all 4 Mbyte arrays must precede any 1 Mbyte arrays in the CPU card cage.

5. Turn power on.
6. Run the Off-Line memory diagnostic.
7. Coolstart or cold load the computer from the back-up media and reconfigure for the added memory.
8. Perform a sysdump to create new back-up media with the new memory configuration on it.




Figure 1. CPU Bay Card Cage, Rear View